



- 1** Verify all electrical power is disconnected in the electrical junction box.
- 2** Disassemble top plate from the bottom canopy by removing four screws on front canopy, separate both pieces from each other.
- 3** Feed the power lines from junction box through the cross bar pattern in top plate.
- 4** Secure channel mounting bracket (fig 1) to the ceiling using four anchor screws
- 5** Secure plate onto electrical junction box.(fig 1)
- 6** Hook the bottom plate to the safety bracket and suspend bottom canopy gently.
- 7** Using the wire nuts provided, connect the junction box white, black and ground wires to the canopy wires. (Fig 2)
- 8** Gently lift and position and align the bottom plate to the four posts on the top bracket. (fig 3)
- 9** Secure the four posts using the decorative mounting screws. (fig 3)
- 10** Install Lamps into the four sockets provided on bottom canopy. (fig 4).
- 11** Install decorative crystal ball strings onto bottom plate. (fig 5).