



RGB Mirror Remote Control Re-set Instructions

1. Take one battery and have it out of the remote.
2. Make sure there is no power running to the mirror.
3. Press the battery in.
4. Press small asterisk on remote control as soon as possible while red light is glowing.
5. Plug in power within 4 seconds of pressing the asterisk.
6. Hit power button on remote control.

Remote should be working with the mirror, if not, please contact Customer Service.

**2630 FLOSSMOOR ROAD SUITE 102
FLOSSMOOR, IL 60422-1560
TELEPHONE: (312) 240-0400 FAX: (866) 300-9283**